

## MINORS REPAIRS



New 120 grit sand paper



Clean Cotton cloth



Repair Kit



Gently sand in the directions of the strips with 120 grit sandpaper on a pole sander to open the wood pores



Apply impregnating oil with the scotch brite to make penetrate oil in the pores of wood



Wait a few minutes then "dry" off the floor with a clean cotton cloth



Wait 24 hours, apply the finishing oil with a clean cotton cloth and "dry" off the floor

**Always hang up your used covers and wipes to let them dry before throwing them in the garbage to avoid risk of combustion**