

MINORS REPAIRS



New 120 grit sand paper



Clean Cotton cloth



Repair Kit



Gently sand in the directions of the strips with 120 grit sandpaper on a pole sander to open the wood pores



Apply impregnating oil with the scotch brite to make penetrate oil in the pores of wood



Wait a few minutes then "dry" off the floor with a clean cotton cloth



Wait 24 hours, apply the finishing oil with a clean cotton cloth and "dry" off the floor

Always hang up your used covers and wipes to let them dry before throwing them in the garbage to avoid risk of combustion