

APPLICATION OF OILS

(Impregnating oil and finishing oil)

Necessary materials



NEW 120 GRIT SAND PAPER



VACUUM



BROOMSTICK, SIGNATURE APPLICATOR AND COVER



CLEAN COTTON CLOTH



ROLLER TRAY LINER, IMPREGNATIVE OIL AND
FINISHING OIL

STEPS



Gently sand in the directions of the strips with 120 grit sandpaper on a pole sander to open the wood pores



Vaccum the sanded surface to remove all residue



Saturate the wood uniformly with impregnating oil with your Signature applicator



Wipe off excess oil with your clean cotton cloth



Let dry 24 hours



Apply finishing oil in the same manner as impregnating oil and let dry 24 hours

Always hang up your used covers and wipes to let them dry before throwing them in the garbage to avoid risk of combustion