

## MINORS REPAIRS

### Necessary materials



NEW 120 GRIT SAND PAPER



A CLEAN COTTON CLOTH



REPAIR KIT

---

## STEPS



Apply impregnating oil with the scotch brite to make penetrate oil in the pores of wood



Wait a few minutes then "dry" off the floor with a clean cotton cloth



Wait 24 hours, apply the finishing oil with a clean cotton cloth and "dry" off the floor

**Always hang up your used covers and wipes to let them dry before throwing them in the garbage to avoid risk of combustion**