



## **APPLYING REGENERATING OIL**

### **WHAT YOU MUST KNOW**

1. Product is ready-to-use, manufactured containing natural resin and oil
  2. Especially formulated for the restoration your SIGNATURE pre oiled floor
  3. It cleans and saturate in-depth fibres of wood by reviving the color and restoring the oil/wood surface damaged by wear
  4. It is appropriate for residential and commercial use
  5. Prolongs the duration of the original impregnation of your SIGNATURE preoiled floor
- 

### **BEFORE STARTING**

1. Wash the area to be restored with SIGNATURE WOOD SOAP - let dry (20 -30 min)
  2. Shake/stir oil very well just prior to starting application
- 

1. Lightly sand the area to be restored with 120 grit sandpaper to open the pores.
2. Vacuum your floor to remove all dust.
3. Apply REGENERATING OIL to the area to be oiled at edges near baseboards and transitions by hand with clean cloth first, then apply REGENERATING OIL with SIGNATURE APPLICATOR on a pole sander in the main area.
4. To avoid accumulations of oils, extend the oil until the wood is completely saturated.
5. 15 minutes later, remove the excess oil with a clean cloth.
6. Work in 15-minute sections at a time.