

APPLYING REGENERATING OIL

WHAT YOU MUST KNOW

- 1.** Product is ready-to-use, manufactured containing natural resin and oil
 - 2.** Especially formulated for the restoration your INTEMPOREL pre oiled floor
 - 3.** It cleans and saturate in-depth fibres of wood by reviving the color and restoring the oil/wood surface damaged by wear
 - 4.** It is appropriate for residential and commercial use
 - 5.** Prolongs the duration of the original impregnation of your INTEMPOREL preoiled floor
-

BEFORE STARTING

- 1.** Wash the area to be restored with INTEMPOREL WOOD SOAP - let dry (20 -30 min)
- 2.** Shake/stir oil very well just prior to starting application

- 1.** Scuff (sand lightly) the area to be restored with 120 grit sandpaper on a pole sander
- 2.** Vaccum your floor to remove grit and dust
- 3.** Apply REGENERATING OIL to the area to be oiled at edges near baseboards and transitions by hand with clean cloth first
- 4.** Then apply REGENERATING OIL with INTEMPOREL APPLICATOR on a pole sander in the 'main area' by section of 4 boards at a time with a motion parallel to wood flooring strips
- 5.** 'Dry' section just oiled with a clean cloth