

REGULAR WASHING OF AN INTEMPOREL PRE OILED FLOOR

WOOD SOAP

WHAT YOU MUST KNOW

1. Formulated from vegetable oils WOOD SOAP is specially manufactured for the ongoing cleaning and maintenance of an INTEMPOREL preoiled floor
 2. This product is concentrated, you must dilute it in water
 3. It is appropriate for residential and commercial use
-

BEFORE COMMENCING REGULAR CLEANING AND MAINTENANCE

1. Wait at least 21 days after the oil application to allow the oil to fully cure
 2. Use only Intemporel cleaning and maintenance products on your INTEMPOREL preoiled floor (other than clean lukewarm water)
 3. Sweep or vacuum your floor regularly to remove dust and grit
-

1. Add 1 capful (10ML) per litre of lukewarm water
2. Always clean your floor with a well wrung mop. It is recommended to use 2 buckets. The first bucket containing INTEMPOREL WOOD SOAP diluted in water and the second bucket containing clean water to rinse dirt out of the mop (alternate to using 2nd bucket: rinse the mop directly under the faucet to clean it)
3. Wash your floor with a motion parallel to wood flooring strips. Rinse the mop regularly in the 2nd bucket in order to eliminate dirt accumulating in the WOOD SOAP, change the water in the 2nd bucket regularly, especially during the first wash following installation
4. Let the floor dry without rinsing